

smoothskins

Autocare Systems

Installation Instructions – Plectrum Clip Method

Notes:

1. Remove boot privacy blind if applicable; this can be refitted on completion of installation.
2. Remove any dirt, dust etc. from carpeted areas of the boot (including seat backs).

FITTING SEAT BACK PANELS

- Place seats in horizontal (flat) position
- Identify (using CONTENTS LIST) which panel fits which seat back
- Place panels in position, with clips exposed and pointing upwards
- Slide Panels into position, ensuring clips slide behind the back of the seat ABOVE the carpeted seat back area
- Smooth panels out and place seats in upright position as far back as they will go

FITTING SIDE PANELS

- Identify (using CONTENTS LIST) the LEFT and RIGHT side panels, as viewed from the rear of the vehicle
- Turn the clips to point upwards and slide in to position just above the carpeted area
- Leave the clips which are to fit behind the rubber trim in boot opening in the closed position
- Carefully open the rubber trims with a blunt object (a teaspoon handle is ideal) and ease the clips into position behind the rubber trim.

BOOT FLOOR MAT & BUMPER PROTECTOR

- Place in position, pushed up against rear seats
- Smooth sides in to position (Your Bumper protection is already attached to the boot mat with Velcro – please ensure it is folded in to the boot area and the boot catch lock is not impeded by the protector)

Any problems, call our helpline on 07017 426 121

www.smoothskins.co.uk

Unit 1 - Cleadon Lane Industrial Estate-East Boldon-Tyne and Wear-NE36 0AH