

Installation Instructions – Plectrum Clip Method

Notes:

1. Remove boot privacy blind if applicable; this can be refitted on completion of installation.
2. Remove any dirt, dust etc. from carpeted areas of the boot (including seat backs).

FITTING SEAT BACK PANELS

- Place seats in horizontal (flat) position
- Identify (using CONTENTS LIST) which panel fits which seat back
- Place panels in position, with clips exposed and pointing upwards
- Slide Panels into position, ensuring clips slide behind the back of the seat ABOVE the carpeted seat back area
- Smooth panels out and place seats in upright position as far back as they will go

FITTING SIDE PANELS

- Identify (using CONTENTS LIST) the LEFT and RIGHT side panels, as viewed from the rear of the vehicle
- Turn the clips to point upwards and slide in to position just above the carpeted area
- Leave the clips which are to fit behind the rubber trim in boot opening in the closed position
- Carefully open the rubber trims with a blunt object (a teaspoon handle is ideal) and ease the clips into position behind the rubber trim.

BOOT FLOOR MAT & BUMPER PROTECTOR

- Place in position, pushed up against rear seats
- Smooth sides in to position (Your Bumper protection is already attached to the boot mat with Velcro – please ensure it is folded in to the boot area and the boot catch lock is not impeded by the protector)

Any problems, call our helpline on 07496 870253