



Autocare Systems

Installation Instructions – Velcro Method

Notes:

1. Remove boot privacy blind if applicable; this will refit on completion of installation.
2. Remove any dirt, dust etc. from carpeted areas of the boot (including seat backs).

FITTING SEAT BACK PANELS

- Place seats in horizontal (flat) position
- Identify (using CONTENTS LIST) which panel fits which seat back
- Place panels in position, following the shape of the seats
- Place seats in upright position as far back as they will go

FITTING SIDE PANELS

- Identify (using CONTENTS LIST) the LEFT and RIGHT side panels, as viewed from the rear of the vehicle
- Follow the shape of the side panels, ensuring the back edge follows the angle of the seat back.
- Once the Velcro has gripped the panel, smooth out by hand

BOOT FLOOR MAT & BUMPER PROTECTOR

- Place in position, pushed up against rear seats
- Smooth sides in to position (Your Bumper protection is already attached to the boot mat with Velcro – please ensure it is folded in to the boot area and the boot catch lock is not impeded by the protector)

Any problems, call our helpline on 07496 870253